HCP COMPATIBILITY OVERVIEW

Issue 06 | 2024

HÖRMANN

HCP compatibility overview

Issue 06 | 2024

EXPAND YOUR POSSIBILITIES. Via the HCP interface, you can network your garage door and entrance gate operators as well as industrial door operators with external Smart Home systems using optional modules. In addition, you can add further connections or control functions to your operators via adapters.

Operators		Series 4		Series 3						RollMatic	
		SupraMatic 4	ProMatic 4	SupraMatic 3	SupraMatic HT3	ProMatic 3	Liftronic 500	Liftronic 700-2	Liftronic 800-2	RollMatic 2	RollMatic 1
Smart Home gateways	Homematic IP (eQ-3)	○	○	●1)	●	–	–	○	○	○	–
	IT-WLAN gateway (Apple)	○	○	●1)	●	–	–	○	○	○	–
	WLAN gateway (Apple)	○	○	●1)	●	–	–	○	○	○	–
	X3D gateway (Delta Dore)	○	○	●1)	●	–	–	○	○	○	–
	KNX gateway	●4)	●3)	–	–	–	–	●2)	●2)	●2)	–
	Loxone gateway	●4)	●3)	●1)	●	–	–	●2)	●2)	●2)	–
Radio receiver	ESE	○	○	●1)	●	–	–	○	○	○	–
	ESE BS HCP	●	●	–	–	–	–	●	●	●	–
Universal adapter print For choosing direction (open / stop / close) via external control elements and / or for controlling the operator light and partial opening function	UAP 1	○	○	●1)	●	–	–	○	○	○	–
	UAP 1 HCP	●	●	–	–	–	–	●	●	●	–
Climatic sensor For detecting the air humidity inside the garage	HKSI	○	○	●1)	●	–	–	○	○	○	–
	HKSI-1	●	●	–	–	–	–	●	●	●	–
Option relay For controlling a garage light, warning light or limit switch reporting	HOR 1	○	○	●	●	–	–	○	○	○	●
	HOR-HCP	●	●	–	–	–	–	●	●	●	–

— = Not compatible
● = Compatible
■ = Compatible, not approved
○ = Compatible via adapter print HAP 1 HCP
1) = from index Ci from 07-2013
2) = from index B0 from 03-2021
3) = from index B3 from 03-2021
4) = from index B4 from 03-2021

HÖRMANN

Entrance gate operators

Use		LineaMatic	LineaMatic 2	RotaMatic	RotaMatic 2	VersaMatic	STA 500 FU
Smart Home gateways	Homematic IP (eQ-3)	● 2)	●	● 4)	●	●	–
	IT-WLAN gateway (Apple)	–	–	–	–	–	–
	WLAN gateway (Apple)	● 2)	●	● 4)	●	●	○
	X3D gateway (Delta Dore)	● 2)	●	● 4)	●	●	–
	KNX gateway	–	–	–	–	–	●
	Loxone gateway	●	●	●	●	●	●
Radio receiver	ESE	● 2)	●	● 4)	●	●	○
	ESE BS HCP	–	–	–	–	–	●
Universal adapter print — For choosing direction (open / stop / close) via external control elements and / or for controlling the operator light and partial opening function	UAP 1	●	●	●	●	●	–
	UAP 1 HCP	–	–	–	–	–	–
Climatic sensor — For detecting the air humidity inside the garage	HKSI	■	■	■	■	■	–
	HKSI-1	–	–	–	–	–	–
Option relay — For controlling a garage light, warning light or limit switch reporting	HOR 1	●	●	●	●	●	–
	HOR-HCP	–	–	–	–	–	–

Industrial operators

Use		WA 300 R S4	WA 300 S4	WA 500 FU / ITO 500 FU
Smart Home gateways	Homematic IP (eQ-3)	● 1)	● 5)	–
	IT-WLAN gateway (Apple)	● 1)	● 5)	–
	WLAN gateway (Apple)	● 1)	● 5)	●
	X3D gateway (Delta Dore)	● 5)	● 5)	–
	KNX gateway	–	–	● 3)
	Loxone gateway	–	–	● 3)
Radio receiver	ESE	● 5)	● 5)	○
	ESE BS HCP	–	–	●
Universal adapter print — For choosing direction (open / stop / close) via external control elements and / or for controlling the operator light and partial opening function	UAP 1-300	●	●	–
	UAP 1 HCP	–	–	–
Climatic sensor — For detecting the air humidity inside the garage	HKSI	● 5)	● 5)	–
	HKSI-1	–	–	–
Option relay — For controlling a garage light, warning light or limit switch reporting	HOR 1	●	●	–
	HOR-HCP	–	–	–

— = Not compatible
● = Compatible
■ = Compatible, not approved
○ = Compatible via adapter print HAP 1 HCP
1) = from index C from 08-2013
2) = from index E from 07-2013
3) = from index B1 from 06-2021
4) = from index G from 08-2013
5) = from index D from 11-2013

HÖRMANN

HCP compatibility overview

Issue 06 | 2024

Combinations		Homematic IP (eQ-3)	IT-WLAN gateway (Apple)	WLAN gateway (Apple)	X3D gateway (Delta Dore)	KNX gateway	Loxone gateway	ESE	ESE BS HCP	UAP 1 / UAP 1-300	UAP 1 HCP	HKSI	HKSI-1	HOR 1	HOR-HCP
Smart Home gateways	Homematic IP (eQ-3)	–	–	–	●	○	○	●	○	–	○	●	○	●	○
	IT-WLAN gateway (Apple)	–	–	–	●	○	○	●	○	–	○	●	○	●	○
	WLAN gateway (Apple)	–	–	–	●	○	○	●	○	–	○	●	○	●	○
	X3D gateway (Delta Dore)	●	●	●	–	○	○	–	○	●	○	–	○	●	○
	KNX gateway	○	○	○	○	–	□	○	□	○	□	○	□	○	□
	Loxone gateway	○	○	○	□	–	–	○	□	–	□	○	□	○	□
Radio receiver	ESE	●	●	●	–	○	○	–	○	●	○	–	○	●	○
	ESE BS HCP	○	○	○	○	□	□	○	–	○	□	○	□	○	□
Universal adapter print For choosing direction (open / stop / close) via external control elements and / or for controlling the operator light and partial opening function	UAP 1 / UAP 1-300	–	–	–	●	○	–	●	○	–	○	●	○	●	○
	UAP 1 HCP	○	○	○	○	□	□	○	□	○	–	○	□	○	□
Climatic sensor For detecting the air humidity inside the garage	HKSI	●	●	●	–	○	○	–	○	●	○	–	○	●	○
	HKSI-1	○	○	○	○	□	□	○	□	○	□	○	–	○	□
Option relay For controlling a garage light, warning light or limit switch reporting	HOR 1	●	●	●	●	○	○	●	○	●	○	●	○	–	○
	HOR-HCP	○	○	○	○	□	□	○	□	○	□	○	□	○	–

— = Cannot be used in conjunction
● = Can be used in conjunction with black Y-piece
○ = Compatible via adapter prints HUB 3 and HAP 1
□ = Compatible via adapter print HUB 3

HÖRMANN